the WALL

MULTIVIEWER
CONTROL
MADE SMART

LAWO

POWERFUL
FAST & EASY
TIME-SAVING

the WALL

MULTIVIEWER CONTROL MADE SMART

the WALL

This is the tool you have always dreamed of for setting up and controlling multiviewers – smart, fast, easy and fun! With the WALL you can configure any monitor wall, route signals, change mosaic layouts or save and load user presets – all done by a comfortable app. the WALL is the ideal solution for operators and EIC to flexibly configure monitor walls in OBs or studios. In the frantic live production environment with its demands for fast changing production and workflow setups, the WALL enables every member in the production team to change their monitor wall layouts in no time and on-the-fly. Instead of operating specific multiviewer configuration software or asking the EIC for a time consuming change of a layout, you can change all kinds of multiviewers with just one tool. the WALL with its elaborate reformatting algorithms

talks directly to the multiviewer hardware and enables easy access through a touchscreen optimized GUI for mobile control. The GUI runs on a HTML5 basis, thus being independent from any mobile device manufacturer. Users can run the software app on any modern stationary or mobile device possible, indifferent of its OS – iOS, Android, Windows, Linux. The majority of the functionality is comfortably operable via drag & drop and changes will be stored in a user managed environment, if required hosted in the cloud. Swapping productions from one OB to another or using preferred multiviewer setups in any control room – the WALL makes it possible. With the WALL, Lawo introduces the next level of efficiency and usability.

"the WALL has been enormously helpful and I honestly couldn't imagine going back to a truck without the WALL!"

Gary Morrill, NEP Supershooters

"the WALL helps us get our job done because of the time saved. It's one more piece of setup that can be handed off to users in the truck instead of relying on the EIC to build each person's wall."

John Widmer, EIC, NEP Supershooters

Saved Source Filters
For fast operation, your favorite searches are stored with quick access keys.

Source Selector
Drag & drop all sources you want to monitor from the Source Selector.

Source Search Filter
Find the sources you search for instantly by just typing in a fragment of a source name.

User Login
Make it your own - the WALL manages all configuration data individually for an unlimited number of users.

Monitor Wall
The monitor wall area represents the physical wall you're configuring right now.

PIP Source Window
The PIP Source Window indicates on the fly how the final layout of your monitors will look like.

Monitor Panel

Global View & Global Drop Zone
You are here! The global view helps you navigate large wall layouts and it quickly helps you to assign attributes to all monitors of the wall.

Toolbars
With the "Files" toolbox you can load monitor wall configurations from a local or networked database.

Use the "Walls" toolbox to choose the physical monitor wall within your OB Van or Studio, which you want to control.

In the "Layouts" toolbox, you select individually designed layouts for the monitors of your wall.

Tune up your PIPs easily by designing UMD's, frame boarders, frame colors, and many other parameters from the "Attributes" toolbox.

Connectivity Status
All data is hosted, centrally, in a network repository.

Orphan Bin
The Orphan Bin - much more than yet another clipboard.

Trash

Swap, Copy, Move Mode Selector
Swap, copy and move layouts and/or sources across the monitors of your wall.

the WALL

MULTIVIEWER
CONTROL
MADE SMART

HEADQUARTERS

Lawo AG
Rastatt
GERMANY
+ 49 7222 1002 0
sales@lawo.com

INTERNATIONAL OFFICES

BENELUX	+ 31 6 54 26 39 78
CANADA	+ 1 416 292 0078
CHINA	+ 86 10 6439 2518
NORWAY	+ 47 22 106110
SINGAPORE	+ 65 9818 3328
SWITZERLAND	+ 49 7222 1002 0
UK	+ 44 333 444 5296
USA	+ 1 888 810 4468

RENTAL SERVICE

+ 49 7222 1002 0
rental@lawo.com

www.lawo.com

LAWO